



68F-DE\EL-MR – Pre-Action

Single or Double-Interlock Pre-Action Valve
Electrically Actuated
Manually-Reset

IOM

Installation • **O**peration • **M**aintenance



Installation, Operation & Maintenance

This document specifies the operating concept of OCV pre-action valve model 68F-X-DE\EL-MR - Pre-Action (X refers to valve size in Inch), FM approved when trimmed per the following technical data sheet

Please review the safety instructions at the end of this document prior to commissioning the valve for use

PRE-ACTION VALVE MODEL 68F-DE\EL-MR General Description

OCV pre-action valve model 68F-X-DE\EL-MR is a globe/weir-type hydraulic valve, actuated automatically or manually.

The valve is mounted on the upstream side of a fire-suppression sprinkler system, preventing flow into the system in the “set” condition.



Operating pressures

- Pressure rating up to 25 bar \ 375 psi
- Minimum system water pressure 1.5 bar \ 22 psi

FM approved working pressures

- 2" - 8": 25 bar \ 375 psi

Available end connections

- Flanged: 2" – 8"
- Grooved: 2" – 8"

Available body & cover and trim materials

Standard Materials

| Body & Cover | Trim components | Tube / Tube Fittings | Diaphragm |
|------------------------|-----------------|-----------------------|-----------|
| Ductile Iron ASTM A536 | Bronze/Brass | Copper / Bronze/Brass | NR |

Other materials available

| | | | |
|----------------------------------|---------------------|--------------|----------|
| Stainless Steel ASTM A351 CF8M | Nickel Plated Brass | SST316 | Neoprene |
| Cast Steel ASTM A216 WCB | SST316 | Super Duplex | EPDM |
| Cast Steel ASTM A352 LCB | Super Duplex | MONEL® | NBR |
| Ni-Al Bronze ASTM B148 gr.C95800 | MONEL® | Cu-Ni 90/10 | |
| Duplex Stainless Steel | Aluminum-Bronze | | |
| Super Duplex Stainless Steel | | | |
| Titanium | | | |

PRE-ACTION VALVE MODEL 68F-DE\EL-MR

General Description (refer to figures 2&3)

“Set” condition:

1. In the “set” condition, the pre-action valve is held closed drip tight by the upstream water pressure, trapped in the valve's control chamber. The water pressure enters the control chamber through the priming line ball valve [b1], a Y-type strainer [c], a check valve [d] and a DMR (Manual Reset) latching relay [r].

“Fire” conditions and pre-action valve actuation:


1. The pre-action valve is actuated when a 2/2-way normally closed solenoid valve [a] is energized (or the coil of a continuously energized ED 100% normally open solenoid is de-energized for SIL 3-4 rated systems). The electric interlock functionality is controlled through the fire control panel.
2. In case of failure of the automatic actuation system, manual emergency actuation is possible.
3. Pre-action valve actuation causes the DMR latching relay [r] to latch open, allowing the water to drain from the valve's control chamber. Once actuated, the valve must be manually reset by pressing the DMR's latching relay [r] knob.

Manual emergency actuation:

1. The manual emergency actuation valve [b2] may be located inside a metal box or over a panel. If in a box – first lift the cover - and turn the handle as shown on the plaque in the box.

Closing the pre-action valve is possible only after:

1. Shutting the isolation valve [i1] (If the priming line is connected to the upstream of the isolation valve).
2. De-energizing the solenoid [a].
3. Verifying the manual emergency actuation ball valve [b2] is closed.
4. Manual-reset by holding the DMR's [r] knob until the pre-action valve has closed.



PRE-ACTION VALVE MODEL 68F-DE\EL-MR


Pre-Installation (refer to figures 2&3)

1. The pre-action valve is factory trimmed for both vertical (with the upstream positioned at the bottom) and horizontal installation - out of the box, requiring no changes or tooling.
2. Sufficient space for maintenance should be left around the pre-action valve.
3. A manual isolating valve (supplied by 3rd party) should be assembled upstream of the pre-action valve for maintenance purposes.
4. Flush the pipelines prior to valve installation. If anti-corrosion, anti-freeze or any other type of additives are to be used, please consult OCV FP division concerning potential damage to the valve and its components.
5. The pre-action valve should be positioned in such a way that allows easy access to the emergency manual actuation valve [b2].
6. The priming control trim's ball valve [b1] should be connected to the main supply pipe upstream of the isolating valve [i1], unless factory preassembled with the priming line ball valve [b1] pre-connected to the valve's upstream port.
7. Verify minimum system water pressure (see **Operating Pressures**).
8. Verify that the manual emergency actuation valve [b2] is closed.
9. Wire all releasing and detection components to the F&G panel according to the wiring diagrams provided by the manufacturers of the F&G panel and the electrical components.
10. Connect the water motor alarm (if supplied) to the alarm test trim's isolation ball valve [b5].
11. A drain for the water drained during the valve's test & working procedures should be prepared. The drain valves [j1, j2] (if supplied), the outlet pipes of the solenoid [a] and the manual emergency actuation valve [b2] should be drained appropriately.

PRE-ACTION VALVE MODEL 68F-DE\EL-MR

Pre-Installation (refer to figures 2&3)

Fig. 1- General layout



PRE-ACTION VALVE MODEL 68F-DE\EL-MR **System & Design Requirements (refer to figures 2&3)**

Temperature

If freezing conditions are expected, prior to being exposed, the control valve should be properly drained and dried to avoid ice formation which may cause damage to the valve and trim. Consult OCV for further technical support relating to extreme weather conditions.

Electrical requirements

The pre-action valve is controlled and actuated by a detection system comprised of electrical components such as heat/smoke/other detectors, and/or electric manual pull stations, which are wired to a F&G panel (Fire & Gas releasing control panel).

All releasing and detection components should be wired to the F&G panel, according to the wiring diagrams provided by the manufacturers of the F&G panel and the electrical components.


The owner should consult local/national authorities having jurisdiction regarding installation criteria of the electric circuitry.

Pneumatic air (or nitrogen gas) supply system

Pneumatic air (or nitrogen gas) pressure should be regulated by an air compressor or by OCV PPCS.

PRE-ACTION VALVE MODEL 68F-DE\EL-MR

Fig. 2- System P&ID



* When a PPCS is supplied, check-valve [d1] & restrictor [e1] are redundant (not supplied)

| Integral System Items | |
|-----------------------|-------------------------------------|
| Item # | Description |
| v | Hydraulic valve |
| a | 2/2-Way solenoid |
| b1 | Priming line ball valve |
| b2 | Emergency manual activation valve |
| b3 | Alarm trim - test ball valve |
| b4 | Alarm trim - drain\purge ball valve |
| b5 | Alarm trim - isolation ball valve |
| c | Y-Type strainer |
| d, d1 | Check valve |
| d3 | Riser check valve |
| r | DMR (latching manual-reset device) |
| e1 | Restrictor |
| f | Drain tube |
| g1, g2 | Pressure gauge |
| h | Drip valve |
| p3 | Pressure switch high - water |
| p4 | Pressure switch low - air |

| Optional System items | |
|-----------------------|----------------------|
| Item # | Description |
| | Alarm Test Trim |
| | See Optional Add-Ons |


| Out Of Scope items | |
|--------------------|-----------------|
| Item # | Description |
| i1 | Isolating valve |
| t | Drain funnel |

PRE-ACTION VALVE MODEL 68F-DE\EL-MR

Fig. 3 - Alarm Test Trim & Optional Add-Ons

| Optional Add-Ons | |
|------------------|-------------------------------------|
| Item # | Description |
| b3 | Alarm trim - test ball valve |
| b4 | Alarm trim - drain\purge ball valve |
| b5 | Alarm trim - isolation ball valve |


| Optional Add-Ons | |
|------------------|---|
| Item # | Description |
| j1, j2 | Upstream, Downstream drain valve |
| g3 | Cover pressure gauge |
| g4 | Downstream pressure gauge |
| p1 | Cover pressure switch low - water |
| p3 | Downstream pressure switch high - water |
| i | Water motor alarm |
| l | Position Indicator |
| ZSO | Proximity switch - open |
| ZSC | Proximity switch - closed |
| s | Spring |




* Optional add-ons may be supplied independently, without the alarm test trim's integral items

Fig. 4 - PPCS (Pneumatic Pressure Control System) P&ID

| PPCS (Optional) - System items | |
|--------------------------------|--------------------------------------|
| Item # | Description |
| b8 | Air supply - Inlet isolating valve |
| b9 | Air supply - Outlet isolating valve |
| b10 | Air supply - Override valve |
| c | Y-Type strainer |
| d | Check valve |
| e3 | Restrictor |
| n1 | 68-410 Pressure reducing pilot |
| T | Air accumulator reservoir (Optional) |



| Pneumatic trim without PPCS System items | |
|--|--------------------------------------|
| Item # | Description |
| d1 | Check valve |
| e2 | Restrictor |
| p2 | Pressure Switch Low - air (Optional) |



Installation, Operation & Maintenance

PRE-ACTION VALVE MODEL 68F-DE\EL-MR

Control Trim Connection (refer to figures 2&3)

Note: if using an external pressure source, it should be at a pressure equal or higher than the maximal upstream pressure.

1. The pre-action valve's control chamber is connected to a pressure source upstream of the isolating valve [i1], through the priming line ball valve [b1], unless factory preassembled with the priming line ball valve [b1] pre-connected to the valve's upstream port.
2. The upstream control trim includes the following items:
 - Priming line ball valve [b1].
 - Y-Type strainer [c].
 - Check valve [d].
 - DMR latching relay [r].
3. The DMR latching relay [r] has two positions:
 - 'Closed' - prevents draining of the pre-action valve's control chamber.
 - 'Latched-Open' - allows draining of the control chamber, latching open the pre-action valve. Manual-resetting is accomplished by holding the DMR's [r] knob until the pre-action valve has closed.
4. The 2/2-way N.C. solenoid [a] is connected to the F&G panel. When energized, the 2/2-way N.C. solenoid [a], releases the pressure from the control chamber, opening the pre-action valve.

Note: Ball valves [b3-b5] are part of the alarm test trim and supplied upon request (optional). Ignore any reference to them if they do not exist.

5. A water motor alarm [i] may be connected to the pre-action valve via an optional alarm test trim. The alarm test trim consists of:
 - Ball valve [b5], which is normally-open.
 - Ball valve [b3], which is normally-closed and allows testing the alarm without opening the pre-action valve.
 - Ball valve [b4], which is normally-closed and allows draining the alarm test trim and purging it from corrosive fluids if necessary.
6. A low-pressure drip valve (relief valve) [h], is mounted on a downstream port of the pre-action valve, as a safety device against faulty sealing of the pre-action valve, which may be caused by foreign objects or unclean water. The drip valve allows small quantities of water to be drained from the system but shuts instantly when the pre-action valve is actuated and high pressure is present.
7. Upstream and downstream ports on the pre-action valve allow connecting a drain valve [j1, j2] (optional).
8. Pressure gauges allow visual inspection of the upstream [g1], supervisory [g2], control chamber [g3] (optional) and downstream [g4] (optional) pressures.
9. Pressure switches are connected to the valve's control chamber [p1] (optional), the closed sprinkler-line [p4] and the valve's downstream port [p3], allowing an electric indication of dropping air pressure or opening of the pre-action valve.

Installation, Operation & Maintenance

PRE-ACTION VALVE MODEL 68F-DE\EL-MR

Commissioning Procedure (refer to figures 2&3)

Note: The following procedures should be carried out as written, in addition to relevant NFPA demands or other local applicable regulations. It is recommended that the installation and adjustment be performed by qualified personnel.

Note: The steps listed below should be performed when initially placing the valve in service, after a test of the fire protection system has been carried out or after the system has operated, following a fire.

Note: Drain valves [j1, j2,] are supplied upon request (optional). Ignore any reference to them if they do not exist

Note: If water should not be allowed into the system during commissioning or tests, a downstream drain valve should be installed. Open this drain valve prior to resetting the valve and close it after the valve has been commissioned.

Drain the system:

1. Close the isolating valve [i1] and the priming line ball valve [b1].
2. Open existing drain valves [j1, j2,] and all auxiliary drains in the system.
3. Once water has stopped discharging, close existing drain valves and all auxiliary drains in the system, except for the upstream drain valve [j1].

Reset the valve to its “set” position:

1. Follow Pre-Installation procedure (see **Pre-Installation**).
2. Reset the electric detection system in accordance with the manufacturer’s instructions to de-energize the 2/2-way N.C. solenoid [a].
3. If the priming control trim’s ball valve [b1] is factory preassembled with the priming line ball valve [b1] pre-connected to the valve’s upstream port, slowly open the isolating valve [i1]. Disregard this stage if the priming control trim’s ball valve [b1] is connected to a pressure source upstream of the isolating valve [i1].
4. Open the priming line ball valve [b1] and press the DMR’s [r] knob until the pre-action valve has closed.
5. Crack open the manual emergency actuation valve [b2] and allow trapped air to vent from the pre-action valve’s control chamber.
6. Immediately close the manual emergency actuation valve [b2] once all air has been vented from the pre-action valve’s control chamber.
7. Press the DMR’s [r] knob until the pre-action valve has closed.
8. Inspect all drain tubes and verify there are no leaks.
9. Verify there is no water leaking from the drip valve [h]. If leaks occur determine the cause of the leak and fix it before moving to the next step.
10. If the priming control trim’s ball valve [b1] is connected to a pressure source upstream of the isolating valve [i1], slowly open the isolating valve [i1]. Disregard this stage if the priming control trim’s ball valve [b1] is factory preassembled with the priming line ball valve [b1] pre-connected to the valve’s upstream port.
11. Close the upstream drain valve [j1] when water starts flowing through it.
12. Ensure the designed pressure in the closed sprinkler-line.
13. Verify the isolating valves [i1, i2] are completely open.
14. If no leaks occur, the pre-action valve is now set for service.

Installation, Operation & Maintenance

PRE-ACTION VALVE MODEL 68F-DE\EL-MR

System Testing Procedure (refer to figures 2&3)

Note: As some of the tests may sound an alarm, it is necessary to alert the owner, local personnel and local fire-fighting authorities before these tests are carried out.

Note: The PSL (Bonnet Pressure Switch Low – Water [p1]), the PSH (Pressure Switch High - water [p3]) and the WMA (Water Motor Alarm [i]) are supplied upon request (optional). Ignore any reference to them if they do not exist.

Note: Ball valves [b3-b5] are part of the alarm test trim and supplied upon request (optional). Ignore any reference to them if they do not exist.

Manual emergency actuation test:

1. Open the manual emergency actuation valve [b2]. Verify the pre-action valve has tripped open.
2. To reset the pre-action valve, refer to “Commissioning Procedure”.

Automatic actuation test:

1. Energize the 2/2-way N.C. solenoid [a] via the F&G panel, according to the instructions provided by the F&G panel manufacturer. Verify the pre-action valve has tripped open.
2. Verify the pressure switches [p3, p4] have indicated that the valve has tripped open and that supervisory pressure has dropped.
3. To reset the pre-action valve, refer to “Commissioning Procedure”.

Alarm test trim check (if supplied):

1. Close ball valve [b5].
2. Open ball valve [b3]. Water will enter the WMA (Water Motor Alarm) and the PSH (Pressure Switch High - water) [p3]. The PSH [p3] will signal and indicate that water pressure is rising downstream and the water motor alarm [i] will sound.
3. Close ball valve [b3] and drain the alarm test trim through ball valve [b4]. Close this valve when water stops flowing.

Installation, Operation & Maintenance


PRE-ACTION VALVE MODEL 68F-DE\EL-MR

Pilot and relay connection

DMR Manual-reset latching relay

Ports C connect to:

- Priming line
- Solenoid
- Manual Emergency Actuation



Installation, Operation & Maintenance

PRE-ACTION VALVE MODEL 68F-DE\EL-MR

Recommended Periodical Check-up and Maintenance

(refer to figures 2&3)

Note: The owner of the valve is responsible for the setting, inspecting, routine testing and the maintenance of the valve as written, in compliance with the applicable standards of the National Fire Protection Association (e.g., NFPA 25), in addition to standards of local authorities having jurisdiction.

Before closing a fire protection system control valve for maintenance or periodical testing, permission to shut down the affected fire protection systems must be obtained from the proper authorities. As per FM 1011, 1012, 1013, fire patrols should be established in the affected areas and all personnel affected by this action should be notified.

It is recommended that all tests and maintenance procedures be carried out by qualified personnel.

Note: As some of the tests may sound an alarm, it is necessary to alert the owner, local personnel and local fire-fighting authorities before these tests are carried out.

Annual operation test

Proper operation of the control valve during fire conditions should be verified at least once a year. The automatic actuation test which simulates the valve's actuation due to a fire event is described in the "System Testing Procedure" under "Automatic actuation test".

Quarterly alarm test trim operation test

Testing the alarm test trim should be performed on a quarterly basis. The alarm test trim check is described in the "System Testing Procedure" under "Alarm test trim check".

Taking the system out of service

Taking the system out of service should only be done under authorization of the appropriate authority having jurisdiction.

When taking the system out of service, the following steps should be taken:


1. Close the isolating valve [i1].
2. Close the priming line ball valve [b1].
3. Open all applicable drain valves [j1, j2,] and all auxiliary drains in the system and allow the system to de-pressurize.
4. Silence all alarms (optional).
5. Relieve all excess pressure from the pre-action valve's control chamber by opening the manual emergency actuation valve [b2].

Installation, Operation & Maintenance

PRE-ACTION VALVE MODEL 68F-DE\EL-MR

Design Data

Head loss chart




Hydraulic characteristics

| Valve Size | | 50 (2") | 65 (2½") | 80 (3") | 100 (4") | 150 (6") | 200 (8") |
|--|------------------------|---------|----------|---------|----------|----------|----------|
| K_v | m ³ /hr @ 1 | 80 | 150 | 200 | 300 | 700 | 1200 |
| C_v | gpm @ 1 psi | 92 | 173 | 231 | 347 | 809 | 1387 |
| K Factor | - | 1.57 | 1.3 | 1.64 | 1.78 | 1.66 | 1.78 |
| Equivalent Pipe Length @ C_{HW} = 120 | meters | 4 | 4 | 6 | 9 | 13 | 20 |
| | feet | 12 | 12 | 21 | 29 | 44 | 66 |
| Control Chamber Displacement Volume | Liters | 0.18 | 0.3 | 0.3 | 0.5 | 2 | 4.8 |
| | Gallons | 0.05 | 0.08 | 0.08 | 0.13 | 0.53 | 1.27 |


Installation, Operation & Maintenance

PRE-ACTION VALVE MODEL 68F-DE\EL-MR Operation Modes


Standby Position




Sprinkler Burst (Valve Remains Closed)




Sensor Line Activated - Pipeline Filled (Single-Interlock Only)




Sensor Line Activated & Sprinkler Burst



Manually Actuated




Reset To Close



Installation, Operation & Maintenance

PRE-ACTION VALVE MODEL 68F-DE\EL-MR Basic Valve Dimensions

| Valve Size | | 50 (2") | | 65 (2½") | | 80 (3") | | 100 (4") | | 150 (6") | | 200 (8") | | |
|------------|-------------|---------------|----------|----------|---------|---------|---------|----------|---------|----------|----------|----------|----------|----------|
| | | mm | inch | mm | inch | mm | inch | mm | inch | mm | inch | mm | inch | |
| Dimensions | 68F Flanged | L | 245 | 9 5/8 | 334 | 13 3/16 | 334 | 13 3/16 | 384 | 15 3/16 | 480 | 18 7/8 | 600 | 23 5/8 |
| | | H | 178 | 7 | 251 | 9 7/8 | 295 | 11 5/8 | 292 | 11 1/2 | 368 | 14 1/2 | 470 | 18 1/2 |
| | | R | 83 | 3 5/16 | 96 | 3 7/8 | 100 | 3 7/8 | 115 | 4 5/8 | 140 | 5 1/2 | 183 | 7 3/16 |
| | | W | 173 | 6 7/8 | 236 | 9 5/16 | 236 | 9 5/16 | 267 | 10 1/2 | 327 | 12 7/8 | 402 | 15 13/16 |
| | | Weight kg/lbs | 10 / 22 | | 20 / 44 | | 21 / 46 | | 33 / 73 | | 52 / 115 | | 92 / 203 | |
| | 68F Grooved | L | 245 | 9 5/8 | 334 | 13 3/16 | 334 | 13 3/16 | 384 | 15 3/16 | 480 | 18 7/8 | 600 | 23 5/8 |
| | | H | 178 | 7 | 225 | 8 7/8 | 225 | 8 7/8 | 265 | 10 1/2 | 327 | 12 7/8 | 417 | 16 3/8 |
| | | R | 83 | 3 5/16 | 67 | 2 5/8 | 67 | 2 5/8 | 89 | 3 1/2 | 100 | 3 7/8 | 130 | 5 1/8 |
| | | W | 173 | 6 7/8 | 236 | 9 3/16 | 236 | 9 3/16 | 265 | 10 1/2 | 327 | 12 7/8 | 400 | 15 11/16 |
| | | Weight kg/lbs | 4.5 / 10 | | 16 / 35 | | 16 / 35 | | 23 / 51 | | 38 / 84 | | 44 / 97 | |





Installation, Operation & Maintenance

PRE-ACTION VALVE MODEL 68F-DE\EL-MR Trim Dimensions

| Size | 50 (2") | | 65 (2½") | | 80 (3") | | 100 (4") | | 150 (6") | | 200 (8") | |
|------|---------|-----|----------|------|----------|-----|----------|-----|----------|-----|----------|-----|
| | Inch | mm | Inch | mm | Inch | mm | Inch | mm | Inch | mm | Inch | mm |
| A | 9 5/8 | 244 | 13 1/8 | 334 | 13 1/8 | 334 | 15 1/8 | 384 | 18 7/8 | 480 | 23 5/8 | 600 |
| B | 10 5/16 | 261 | 10 5/16 | 261 | 10 5/16 | 261 | 10 5/16 | 261 | 10 5/16 | 261 | 11 13/16 | 300 |
| C | 4 13/16 | 122 | 6 5/8 | 167 | 6 5/8 | 167 | 7 5/8 | 192 | 9 3/8 | 240 | 11 13/16 | 300 |
| D | 6 1/8 | 155 | 6 5/16 | 161 | 6 5/16 | 161 | 6 7/8 | 175 | 8 | 204 | 9 1/8 | 232 |
| E | 5 11/16 | 144 | 5 11/16 | 144 | 5 11/16 | 144 | 5 11/16 | 144 | 6 3/8 | 163 | 7 7/8 | 200 |
| F | 3 5/16 | 84 | 3 13/16 | 95.5 | 3 7/8 | 100 | 4 5/8 | 118 | 5 1/2 | 140 | 7 1/8 | 180 |
| G | 8 1/8 | 206 | 10 13/16 | 275 | 10 13/16 | 275 | 11 5/8 | 295 | 13 5/8 | 345 | 17 5/8 | 405 |

* Dimensions are approximate

** Check valve not included in dimensions



Installation, Operation & Maintenance

PRE-ACTION VALVE MODEL 68F-DE\EL-MR

General Description (refer to figures 2&3)

“Trouble” conditions

1.

| Item number | Description | Alarms and visual indications | Corrective action |
|-------------|---|---|---|
| 1 | The valve has accidentally tripped | Water will flow out of the open sprinklers\nozzles. The PSH [p3] will signal and indicate that water pressure is rising downstream and the water motor alarm [i] will sound (if supplied) | Inspect the electrical circuit in the F&G Panel |
| | | | Inspect the solenoid [a] |
| | | | Verify the emergency manual actuation valve [b2] is in its closed position |
| 2 | A pressure switch [p1, p2, p3, p4] fails to give an electrical indication (if supplied) | Water will flow out of the open sprinklers\nozzles with no indication from the pressure switches [p1, p2, p3, p4] | Inspect the electrical circuit connections between the pressure switches [p1, p2, p3, p4] and the F&G Panel |
| | | | Check that water can flow freely into the pressure switches [p1, p2, p3, p4] line connection |
| | | | Verify the pressure switches [p1, p2, p3, p4] are set to the correct trip-point |
| 3 | The water motor alarm [i] does not sound (if supplied) | Water will flow out of the open sprinklers\nozzles but the water motor alarm [i] does not sound | Check for clogging in the alarm test trim's strainer |
| | | | Check that water can flow freely into the alarm test trim and into the WMA [i] |
| | | | Check for any physical obstructions in the WMA [i] |
| | | | Verify the alarm test trim's isolation ball valve [b5] is in its open position |
| 4 | Leakage through the main valve or in the trim | Moisture near trim components | Check for leaking trim components. Any leaks must be corrected |
| | | The drip valve [h] is leaking (water is flowing to the downstream) | |
| | | The PSH [p3] will signal and indicate that water pressure is rising downstream and the water motor alarm [i] will sound (if supplied) | |

2. In case any other problems or difficulties have occurred, please contact OCV or its representatives in your geographical area.

Installation, Operation & Maintenance

Safety Instructions:

PLEASE NOTE

- Before using this product, read and understand the instructions.
- All procedures must be carried out by qualified personnel.
- Make sure that all applicable safety precautions have been taken in addition to these instructions.
- Read this manual along with all the provided data.
- Save these instructions for future reference.

Before disassembly of any accessory or component:

- All internal pressures must be relieved and all media drained from the system in accordance with all applicable procedures.
- Pressure must be 0 (zero) bar/psi.

Before Installation:

- **Flush the lines upstream of the valve. If anti-corrosion, anti-freeze or any other type of additives are used, please consult the documentation or OCV FP division concerning potential damage to the valve and its components.**
- Remove all external and internal packaging along with any temporary protective material.
- Carefully inspect the valve to ensure that no damage has occurred in transit or during subsequent handling.
- Ensure that the valve is the correct type and size and that the identification markings show that the material and pressure/temperature rating is suitable for the required service conditions.
- Read the installation instructions carefully and follow them.
- Ensure that the valve is lifted safely into position without damaging the valve.
- Ensure that the valve is installed so that it can be safely operated and maintained without putting any people at risk.
- Make sure that a firm footing is provided for the person installing the valve with adequate space around the valve to meet operating and maintenance requirements.
- Ensure that there is adequate lighting for valve installation.
- The valve can be installed in any position, but flow direction should match the engraved arrow on the bonnet.

Failure to follow the instructions set forth in this publication could result in property damage, personal injury, or death from hazards that may be associated with this type of equipment.